



Waterless Graffiti Film Installation Instructions

Installation instructions apply to WL (Waterless) Glass Shield, Mirror Shield, and Metal Shield films.

Recommended installation tools:

- Blue Squeegee Card (GST-0015-B)
- White Nylon Scrub Pad (GST-0016)
- Standard Glass Cleaner or Spray Bottle with 1-2 drops of dishwashing detergent
- Lint free paper towels or microfiber towel

Step 1:

Spray the surface with your glass cleaner or soapy water.

Use the White Scrub Pad to thoroughly clean the surface.

Take your paper towel or micro fiber towel and dry surface completely. Take extra time to make the edges clean and the surface lint free.

Surface must be completely dry.

Step 2:

Remove the clear thin release liner using the pull tab.

Step 3:

Line up the top and sides to make sure your film is aligned correctly. Please try to keep the film from adhering to the lower section. Apply pressure to the upper section to make that area adhere to the surface. If you misalign, pull back and try again.

Step 4:

With the upper section adhered and aligned, take the lower section and pull gently out towards you. Then drop the film slowly to allow the film to evenly adhere to the surface.

Step 5:

Take your Blue Squeegee Card and remove any air bubbles from under the film. These will move as you put pressure and push them to an edge.

Step 6:

Spray the film with a light mist of window cleaner and wipe down.

